

1. Turn loop and top set into coupler.
2. Turn the finial onto the nipple.
3. Split the arms evenly, make sure each arm is aligned with the center rod.
4. Please put the tube onto the socket.

