

1. Spread the arms evenly, make sure each arm is aligned with the center rod.
2. Turn the nipple into the coupler.
3. Attach the poly cap on the nipple then secure by the loop.
4. Turn the nipple 1 into the coupler 1.
5. Attach the cover on the nipple 1 then secure by the finial.
6. Attach the glass on the socket then secure by the socket ring.

